

Slide key-ET Fluoro

- Slide 1, 2, -hang on outside of FL room door, bathroom door facing hallway
- Slide 3,4-hang on outside of FL room door, bathroom door facing hallway
- Slide 5,6-hang on outside of FL room door, bathroom door facing hallway
- Slide 7 – hang on footstool tall handle to block entrance to control room
- Slide 8, 9 –hang on wall in changing room by mirror-donning
- Slide 10,11- hang on bathroom door inside FL room-doffing
- Slide 12 – hang on back of door in bathroom-doffing



**Restricted
Access**

Call 733-0506 for Instructions



**Restricted
Access**

Call 733-0506 for Instructions



Hand Hygiene MUST Be
Performed Upon Entering
and Leaving This Room

N95 Masks and Face Shields or Equally Effective
Equipment MUST BE WORN AT ALL TIMES



Hand Hygiene MUST Be
Performed Upon Entering
and Leaving This Room

N95 Masks and Face Shields or Equally Effective
Equipment MUST BE WORN AT ALL TIMES



Do Not Enter Room Until:

Prior to this time, N95 mask is required

Call EVS to initiate clean: 352-256-7435 ET



(Use Air Exchange Chart)



Do Not Enter Room Until:

Prior to this time, N95 mask is required

Call EVS to initiate clean: 352-256-7435 ET

(Use Air Exchange Chart)



**Restricted
Access**

DO NOT ENTER

Donning Area Supplies

1. Mirror (inside dressing room)
2. Small red trash can/regular trash by door
3. Lead aprons
4. Personal N95 masks
5. Paper bags (for N-95 masks after use)
6. Surgical masks (to cover N95)
7. Yellow gowns
8. Face shields (either connected to surgical mask or goggles)
9. Non-sterile gloves (S, M, L, XL)

Donning

Clean Room-changing room

1. Put on lead
2. Put on yellow gown
3. Tie isolation gown at waist
4. Ensure back is fully covered
5. N95 – Put on mask & eye/face protection or CAPR – Put on CAPR hood
6. Put on scrub cap/bonnet
7. Put on non-sterile gloves
8. Move to procedure room to wait for patient
9. Sterile gloves will be put on in the room after moving patient

Doffing Area Supplies

In the room:

1. Hand sanitizer (made sure it works)
2. Red trash can/regular trash can placed by door
3. Non-sterile gloves (S, M, L, XL)

Doffing-STEP 1

While in Room

1. Remove yellow gown and gloves (grasping in front and pull away from body, roll it up into a ball and peel off gloves at the same time and place in trash bag)
2. Perform hand hygiene-Purell
3. Put on new gloves
4. Exit room through bathroom door using elbow to open door

Doffing-STEP 2

Leave Room using bathroom door, once inside bathroom

1. Remove hair bonnet and place in trash
2. Remove gloves
3. Hand hygiene-Purell, put on new gloves
4. Remove surgical mask covering N-95 along with face shield by touching strings/straps as opposed to front of mask and place in trash
5. Remove gloves
6. Hand hygiene-Purell, put on new gloves
7. Remove N95 mask (do not touch front, bottom strap first pulling over head), place mask in paper bag
8. Remove gloves and place in trash
9. Hand hygiene- washing in sink
10. Exit bathroom to hallway and hang lead in changing room across the hall for cleaning

Air Exchange – Room Closed Time

Tower	Description	Room	ACH	Time (min) 99% Efficiency
North	CT 2	G435	12	23
	CT 4	G314	25	13
	Fluoro 6	G303.3	12	23
	Fluoro 7	G303.4	12	23
	IR 11	G302	15	18
	IR 13	G300	15	18
	IR 16	G325	14	20
	MR Control	1111,C1,C3	8	18
	MR Holding	1118	8	46
	MR 1.5T	1109	14	20
	MR 3T	1113	8	35

Tower	Description	Room	ACH	Time (min) 99% Efficiency
South	CT 3	1230.3	6	46
	CT 2	1230.2	6	46
	CT 1	1230.1	6	46
	IR 1	2118	20	14
	MR 1.5T Holding	1219	6	46
	MR 1.5T	1219.2	6	46
East	CT 2	1564	20	14
	Fluoro	1564	15	18
	MR 3T	2762	20	14
	MR 3T	2762.2	20	14